


## 30032 CHAIR



Categories: [3000 Series](#)



### PRODUCT SPECIFICATION

**RECLINER**

CLOSED, OPEN

**leather**

6011-21, 6011-58, 6031-00, 6031-01, 6031-11, 6031-17,  
6031-31, 6031-61, 6120-01, 6120-58, 6120-68, 6147-48,  
6147-61, 6147-62, 6150-10, 6152-32, 6152-58, 6152-62,  
6153-11, 6153-17, 6153-42, 6153-58, 6166-11, 6166-21,  
6166-57, 6166-61, 6167-48, 6167-57, 6172-03, 6172-27,  
6172-32, 6172-48, 6172-56, 6173-03, 6173-07, 6173-61, NONE

**fabric**

4001-08, 4001-68, 4727-61, 4731-31, 4731-91, 4737-61,  
4739-11, 4739-12, 4739-58, 4739-61, 4739-68, 4741-57,  
4741-61, 4743-01, 4743-58, 4746-83, 4753-52, 4755-32,  
4758-11, 4762-01, 4828-03, 4828-08, 4828-17, 4828-58,  
4828-61, NONE